lenovo

Lenovo A859 Quick Start Guide v1.0

Technical specifications



Model and system

System: Android 4.2.2



Size and weight

Width: 73.8 mm Depth: 9.04 mm Height: 144.71 mm Weight: 162.1 g



CPU: MTK6582 Quad Core 1.3 GHz



Camera

Type: CMOS Pixels: 8.0 MP (back) + 1.6 MP (front)



Power and battery

Battery: 2250 mAh



Size: 5.0 inches (diagonal)

Resolution: HD 720P LCD type: IPS



Wireless communication

*Bluetooth 3.0 WI AN WCDMA, GSM



D Based on actual measurements.

* You must be within about 30 feet (10 meters) of a Bluetooth device for it to be connected to the device.


First Glance



- Receiver
- Volume key
- Earphone jack
- On/Off button
- 6 Microphone
- 8 Back camera 9 Speaker
- 3 Front camera
- 6 Micro USB

Preparing your phone


You need to insert the SIM card provided by your carrier to use cellular services. Install your phone as shown.



DO NOT insert or remove the SIM cards while your phone is turned on. Doing so can permanently damage your SIM card or your phone.

Charging the battery

Charge the battery as shown.



Method 1. Connect your phone to a power outlet using the included cable and USB power adapter.

Method 2. Charge the battery using a computer.

- Low battery
- Fully charged
- Charging

For more information about battery safety, see the Important Product Information Guide

Learn more

For more information about Lenovo Mobile Phone functions, Regulatory Notices and other useful manuals, go to http://support.lenovo.com/.

Getting support

For support on network service and billing, please contact your wireless network operator. For instructions on how to use your device, go to https://support.lenovo.com/.

Legal notices

Lenovo, the Lenovo logo are trademarks of Lenovo in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

First Edition (January 2014) © Copyright Lenovo 2014.

Reduce | Reuse | Recycle





5SC9A466WM Printed in China